



8-3-65

FIG. 15 PLUG IN VOX ACCESSORY, MODEL VX-1

OPERATING INSTRUCTIONS

1. Place the VOX-PTT switch in the PTT position and adjust the transceiver for normal push-to-talk operation.
2. Plug in the VX-1 and rotate the VOX GAIN, ANTI-VOX, and DELAY controls fully counter-clockwise. Attach the top of the VX-1 to the 350 back with a G-32 screw.
3. Rotate the transceiver MIC. GAIN fully counter-clockwise. This will prevent audio from being transmitted but will not affect VX-1 during initial adjustments.
5. Place the VOX-PTT switch in the VOX position.
6. While speaking into the microphone in a normal manner, slowly rotate the VOX GAIN control clockwise until the VX-1 keys the transmitter. Do not use more VOX GAIN than necessary to assure positive operation at normal voice levels.
7. Increase the receiver gain until received signals are at a normal volume level. These

signals will trip the Vox when picked up by the microphone.

8. With the microphone held in the normal operating position, very slowly increase the ANTI-VOX until received signals do not trip the Vox.

NOTE: Excessive ANTI-VOX gain will cause received signals to gate the VX-1 off so that no amount of sound at the microphone will key the transmitter. Satisfactory balance between the VOX GAIN and ANTI-VOX is easily obtained when the microphone is at least a foot from the speaker.

9. Adjust the DELAY control to hold the transmitter keyed for the desired interval after you stop talking.

NOTE: A little experimenting on the air will reveal that only a small portion of the first spoken syllable is lost when the VX-1 is actuated. Short DELAY settings will result in most efficient operation.

K4XL's **BAMA**

This manual is provided **FREE OF CHARGE** from the "BoatAnchor Manual Archive" as a service to the Boatanchor community.

It was uploaded by someone who wanted to help you repair and maintain your equipment.

If you paid anyone other than BAMA for this manual, you paid someone who is making a profit from the free labor of others without asking their permission.

You may pass on copies of this manual to anyone who needs it. But do it without charge.

Thousands of files are available without charge from BAMA. Visit us at <http://bama.sbc.edu>