


NATIONAL MODEL
NC-57



NATIONAL MODEL NC-57

NATIONAL MODEL
NC-57

TRADE NAME	National, Model NC-57
MANUFACTURER	National Co., Inc., 61 Sherman St., Malden, Mass.
TYPE SET	AC or Battery Operated Multi-Band Commercial Type Superheterodyne Receiver
TUBES (NINE)	Types, 6SG7 RF Amp., 6SB7Y Converter, 6SG7 1st IF Amp., 6SG7 2nd IF Amp., 6H6 Det.-AVC-ANL, 6SL7GT AF Amp.-BFO, 6V6GT Power Output, OD3/VR-150 Voltage Reg., 5Y3GT Rectifier.
POWER SUPPLY	105-130 Volts AC or 6.3 Volts & 250 Volts DC RATING .67 Amp. @ 117V AC
TUNING RANGE-BROADCAST	560-1550KC SHORT WAVE Band "A" 35.0-54.0MC, Band "B" 12.0-35.0MC, Band "C" 4.4-12.0MC, Band "D" 1.55-4.4MC

DISASSEMBLY INSTRUCTIONS

1. Remove the top and back piece of the cabinet by releasing the ten drive screws at the back which fasten the piece to the chassis and cabinet wrap around.
2. Remove the bottom cover of the receiver which is held in place by four drive screws.
3. Remove the four mounting feet at the bottom of the receiver. These feet are fastened by means of a screw and speed nut arrangement.
4. Unsolder the two loudspeaker leads to the output tube (6V6GT/G). A red lead is soldered to Pin 4 and a blue lead to Pin 3.
5. Remove all knobs from the front of the Receiver. All knobs, with the exception of the main tuning and bandspread tuning knobs, are mounted on flatted shafts by set screws. Replacing the knobs to their original position is assured by use of the flatted shafts.
6. Remove the retaining nuts on the control switch, BAND switch, bandspread tuning control, main tuning control and the SEND-REC switch.

After completing the six steps above, the chassis can be withdrawn from the cabinet. Reassembly of the receiver can be accomplished by following the disassembly procedure in reverse order.


HOWARD W. SAMS & CO., INC.

"The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty by Howard W. Sams & Co., Inc., as to the quality and suitability of such replacement part. The numbers of these parts have been compiled from information furnished to Howard W. Sams & Co., Inc., by the manufacturers of the particular type of replacement part listed."

"Reproduction or use, without express permission, of editorial or pictorial con-

Indianapolis Indiana

tent, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. Copyright 1947 by Howard W. Sams & Co., Inc., Indianapolis, Indiana, U. S. A. Copyright under International Copyright Union. All rights reserved under Inter-American Copyright Union (1910) by Howard W. Sams & Co., Inc." Printed in U. S. of America



87

89

88

5

7

111

A2

105

A1

2

A24

A26

A23

109

115

116

A18

A13

A19

6

8

85

A5

107

A6

4

9

A4

106

10

3

A3

1

A27


A28

A25

86

A15

A20



PARTS LIST AND DESCRIPTIONS

TUBES (SYLVANIA or Equivalent)

ITEM No.	USE	REPLACEMENT DATA		INSTALLATION NOTES
		NATIONAL PART No.	STANDARD REPLACEMENT	
1	RF Amp.	6S57	6S57	
2	Converter	6S57Y	6S57Y	8"K
3	1st IF Amp.	6S57	6S57	9R
4	2nd IF Amp.	6S57	6S57	8BK
5	Det.-AVC-ANL	6H6	6H6	8BK
6	AF Amp.-BFO	6SL7GT	6SL7GT	7Q
7	Power Output	6V6GT	6V6GT	8BD
8	Voltage Reg.	013/VR-150	013/VR-150	7AC
9	Rectifier	5Y3GT	5Y3GT	44J
				5T

CAPACITORS

Capacity values given in the rating column are in mfd. for Electrolytic and Paper Capacitors, and in mmfd. for Mica and Ceramic Capacitors.

ITEM No.	RATING	REPLACEMENT DATA			IDENTIFICATION CODES AND INSTALLATION NOTES
		NATIONAL PART No.	AEROVOX PART No.	CORNELL DUBILIER PART No.	
10A	10 CAP.	AF22J		UF1145	□ Filter
10B	10 450	FR550/25		BR255	TA-525 Cathode Bypass
11	25 25	FR525/25		M-25-25	TA-25 Line Filter
12	20 600	634-01		DT6S1	TPH-6-01 Voltage Reg. Bypass
13	01 400	484-01		DT4P1	ST-4-01 Tone Comp.
14	01 400	484-01		DT4S1	ST-4-01 Audio Coupling
15	01 400	484-01		DT4S1	ST-4-01 " "
16	01 600	684-01		DT4S1	ST-4-01 BFO Coupling
17	01 600	484-01		DT4S1	ST-4-01 Limiter Filter
18	01 300	484-01		DT4S1	ST-4-01 2nd IF Screen Bypass
19	01 400	484-01		DT4S1	ST-4-01 2nd IF Cathode Byp.
20	01 400	484-01		DT4S1	ST-4-01 AVC Filter
21	01 400	484-01		DT4S1	ST-4-01 " "
22	01 400	484-01		DT4S1	ST-4-01 " "
23	01 400	484-01		DT4S1	ST-4-01 " "
24	01 600	684-01		DT6S1	ST-6-01 1st IF Plate Decoupl.
25	01 600	684-01		DT6S1	ST-6-01 1st IF Screen Bypass
26	01 400	484-01		DT4S1	ST-4-01 1st IF Cathode Bypass
27	01 600	684-01		DT6S1	ST-6-01 AVC Filter
28	01 600	684-01		DT6S1	ST-6-01 Conv. Plate Decoupl.
29	01 400	484-01		DT4S1	ST-4-01 Conv. Screen Bypass
30	01 400	484-01		DT4S1	ST-4-01 RF Bypass
31	01 400	484-01		DT4S1	ST-4-01 RF Screen Bypass
32	01 400	484-01		DT4S1	ST-4-01 RF Cathode Bypass
33	2200 500	1467-002		1M5D2	IM-5-22 Output Plate Byp.-Note
34	1000 500	1467-001		1M5D1	IM-5-21 Audio Coupling
35	300 500	1468-003		SM5T3	MOS-3 AF Plate Bypass
36	100 500	1468-001		SM5T1	MOS-3 Diode RF Filter
37	270 500	1468-002		SM5T2	MOS-3 BFO Grid Cap.
38	220 500				Fixed Trimmer
39	100 500	1468-001		SR5T1	Osc. Grid Cap.
40	100 500	1468-001		SR5T1	Fixed Padder
41	510 500				" "
42	1300 500				" "
43	4300 500				" "
44	5 200	1468-000005		SM5V5	MOS-5 RF Coupling-Cer.
45	5 200	1468-000005		SM5V5	MOS-5 " "
46	1000 500	1468-0001		SM5T1	MOS-3 Fixed Padder
47	1000 500	1467-001		1M5D1	IM-5-21 RF Plate Decoupl.
48	100 500	1468-0001		SM5T1	MOS-3 RF Coupling
49	100 500	1468-0001		SM5T1	MOS-3 Fixed Padder
50	10000 300	1467-01		1M3S1	MM-3-11 AVC Filter

Note-Not used in all models.

CONTROLS

ITEM No.	RATING	REPLACEMENT DATA			INSTALLATION NOTES
		NATIONAL PART No.	IRC PART No.	CLAROSTAT PART No.	
51A	500K2		D13-133		AF Gain Control
51B	500K2				Attach to 51A per instructions
51C	Switch		41		" "
52	10K3				RF Gain Control

PARTS LIST AND DESCRIPTIONS (Continued)

R F COILS

R F COILS

ITEM No.	USE	DC RES.		REPLACEMENT DATA	
		PRI.	SEC.	NATIONAL PART No.	MEISSNER PART No.
90	Aut. Coil	2.5Ω	5.2Ω		
91	"	1Ω	1.5Ω		
92	"	1Ω	0Ω		
93	"	1Ω	0Ω		
94	"	0Ω	0Ω		
95	RF Coil	5.5Ω	5.2Ω		
96	"	25.2Ω	1.5Ω		
97	"	5Ω	0Ω		
98	"	2.2Ω	0Ω		
99	"	0Ω	0Ω		
100	Osc. Coil	2Ω	5.5Ω		
101	"	0Ω	0Ω		
102	"	0Ω	0Ω		
103	"	0Ω	0Ω		
104	1st IF	2.2Ω	1Ω		
105	2nd IF	2Ω	2Ω		
106	3rd IF	2Ω	2Ω		
107	B.F. Osc.				
108	Coil		4.6Ω		

DIAL LIGHT

ITEM No.	BASE TYPE	VOLTS	AMPS.	BEAD COLOR	REPLACEMENT DATA		INSTALLATION NOTES
					NATIONAL PART No.	Type #47	
109	RAYONET	0-4	0.15	Brown			

MISCELLANEOUS

ITEM No.	PART NAME	NATIONAL PART No.	NOTES	
			NATIONAL PART No.	NOTES
110	Switch			Band
111	"			Send-Receive
112	"			Tone
113	"			Control
114	Var. Cap.			ALO
115	5 Gauz Var. Cap.			Band Spread
116	"			Rein Tuning

PARTS LIST AND DESCRIPTIONS (Continued)

RESISTORS

ITEM No.	RATING		REPLACEMENT DATA		IDENTIFICATION CODES
	RESISTANCE	WATTS	NATIONAL PART No.	IRC PART No.	
53	1 Meg.		BTS-1 Meg.		Br.-Blk.-Grn. AVC Network
54	150K Ω		BTS-150K		Br.-Grn.-Yl. RF Grid
55	220 Ω				Red-Red-Br. RF Cathode
56	1000 Ω		BTS-1000		Br.-Blk.-Red RF Screen
57	4700 Ω		BTS-4700		Yl.-Vl.-Red RF Plate Decoup.
58	68K Ω		BT-2-68K		Blue-Gray-Or. Voltage Dropping
59	33 Ω				Or.-Or.-Blk. Parasitic Suppressor
60	47K Ω		BTS-47K		Vl.-Vl.-Or. Osc. Grid
61	3900 Ω		BTS-3900		Or.-White-Red Conv. Screen
62	1000 Ω		BTS-1000		Vl.-Vl.-Vl. AVC Network
63	470K Ω		BTS-470K		Br.-Blk.-Red Conv. Plate Decoup.
64	1200 Ω		BTS-1200		Yl.-Red-Red 1st IF Cathode
65	470K Ω		BTS-470K		Yl.-Vl.-Bl. 1st IF Screen
66	1000 Ω		BTS-1000		Br.-Blk.-Red 1st IF Plate Decoup.
67	470K Ω		BTS-470K		Yl.-Vl.-Yl. AVC Network
68	220 Ω		BTS-220		Red-Red-Br. 2nd IF Cathode
69	2200 Ω		BTS-2200		Red-Red-Red 2nd IF Screen
70	2200 Ω		BTS-2200		Red-Red-Red Series "G" Meter
71	2.2 Meg.		BTS-2.2 Meg.		Red-Red-Grn. AVC Network
72	100K Ω		BTS-100K		Br.-Blk.-Yl. Diode Load
73	220K Ω		BTS-220K		Red-Red-Yl. " "
74	1 Meg.		BTS-1 Meg.		Br.-Blk.-Grn. ANL Network
75	1 Meg.		BTS-1 Meg.		Br.-Blk.-Grn. " "
76	10K Ω		BTS-10K		Br.-Blk.-Or. CHO Osc. Plate
77	10K Ω		BTS-10K		Br.-Blk.-Or. CHO Osc. Grid
78	2700 Ω		BTS-2700		Red-Vl.-Red AF Cathode
79	100K Ω		BTS-100K		Br.-Blk.-Yl. AF Plate Load
80	470K Ω		BTS-470K		Yl.-Vl.-Yl. Output Grid
81	330 Ω		BK-2-330		Or.-Or.-Br. Output Cathode
82	4700 Ω		BTS-4700		Yl.-Vl.-Red Tone Comp.
83	22K Ω		BTS-22K		Red-Red-Or. Output Trans. Primary Shunt
84	3900 Ω		AB-4000		Red-Red-Or. Voltage Dropping-See Note

Note-Some models use two 1800 Ω 2 w. resistor in series in this application.

TRANSFORMER (POWER)

ITEM No.	RATING			REPLACEMENT DATA		
	PRI.	SEC. 1	SEC. 2	NATIONAL PART No.	STANCOR PART No.	MERIT PART No.
85	117V AC	620V CT	5.3V AC	K-316	P-6335	T22R04
	②	1.4A DC	2.0A	③		P-2932#

#Drill new mounting holes

FILTER CHOKE


ITEM No.	RATINGS		REPLACEMENT DATA		INSTALLATION NOTES
	TOTAL D.C. CURRENT	D. C. RESISTANCE	NATIONAL PART No.	STANCOR PART No.	
86	1. A.	255 Ω	K-317	C-170C	T-20053


TRANSFORMER (OUTPUT)

ITEM No.	RATING			REPLACEMENT DATA			INSTALLATION NOTES
	IMPEDANCE	DC RES.	DC RES.	NATIONAL PART No.	STANCOR PART No.	MERIT PART No.	
87	4000 Ω	3.4 Ω	500 Ω	NE-189	A-3850	T-2546	A-2530

SPEAKER

ITEM No.	RATINGS		REPLACEMENT DATA		INSTALLATION NOTES
	FIELD PH	VC IMP.	NATIONAL PART No.	JENSEN PART No.	
88	4-5/8"	3.45	ST-107	5A15	
89	4-5/8"	9/16"	1041. F5-V	5A15	





IF = 455 KC

CONTROL SWITCH AT A AND LEFT HAND NOTES OTHERWISE.
 500Ω RESISTIVE SWITCH IN REVERSE POSITION.
 TONE CONTROL ON RIGHT.
 MP GAIN AT MAXIMUM.

VOLTAGE READINGS

Pin	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	
1	6SS7	OV.	OV.	2.5VDC	OV.	2.5VDC	140VDC	5.0VAC	240VDC
2	6SB7Y	OV.	6.0VAC	250VDC	110VDC	+10.0VDC	OV.	OV.	OV.
3	6SB7Y	OV.	OV.	2VDC	OV.	2VDC	70VDC	6.0VAC	250VDC
4	6SB7Y	OV.	OV.	3.2VDC	OV.	2.2VDC	100VDC	6.0VAC	240VDC
5	6B6	OV.	OV.	-1.0VDC	-1.0VDC	-4.0VDC	110VDC	6.0VAC	OV.
6	6AL7GT	OV.	110VDC	1VDC	3VDC	125VDC	OV.	OV.	6.0VAC
7	6V6GT	OV.	OV.	220VDC	250VDC	OV.	240VDC	6.0VAC	10VDC
8	6D5WB-5	OV.	OV.	220VDC	145VDC	OV.	OV.	OV.	OV.
9	6Y3GT	145VDC	280VDC	OV.	210VAC	+0.5VDC	210VAC	OV.	280VDC

TAKEN WITH VACUUM TUBE VOLTMETER.

RESISTANCE READINGS

Pin	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	
1	6SS7	0Ω	0Ω	220Ω	2.5 MΩ	220Ω	50KΩ	.1Ω	50KΩ
2	6SB7Y	0Ω	.1Ω	50KΩ	50KΩ	470Ω	.1Ω	0Ω	5.2Ω
3	6SB7Y	0Ω	0Ω	1.2KΩ	3.7MΩ	1.2KΩ	20KΩ	.1Ω	50KΩ
4	6SB7Y	0Ω	0Ω	220Ω	3.7MΩ	220Ω	50KΩ	.1Ω	50KΩ
5	6B6	0Ω	0Ω	220KΩ	2.2 MΩ	200KΩ	100KΩ	.1Ω	0Ω
6	6AL7GT	500KΩ	150KΩ	2.7KΩ	10KΩ	50KΩ	0Ω	0Ω	.1Ω
7	6V6GT	0Ω	0Ω	50KΩ	50KΩ	470KΩ	300KΩ	.1Ω	300Ω
8	6D5WB-5	1MΩ	0Ω	1MΩ	50KΩ	50KΩ	1MΩ	1MΩ	1MΩ
9	6Y3GT	50KΩ	50KΩ	0Ω	110Ω	50KΩ	100Ω	1MΩ	50KΩ

* CONTROL SWITCH AT ON.
 * CONTROL SWITCH AT OFF.

RESISTANCE READINGS IN THE 8-1 CIRCUITS MAY VARY WIDELY
 ACCORDING TO THE CONDITION OF THE FILTER CAPACITORS

- DC Voltage measurements are at 20,000 ohms per volt; AC Voltages measured at 1,000 ohms per volt.
- Socket connections are shown as bottom views.
- Measured values are from socket pin to common negative.
- Line voltage maintained at 117 volts for voltage readings.
- Nominal tolerance on component values makes possible a variation of ± 10% in voltage and resistance readings.
- Volume control at maximum, no signal applied for voltage measurements.

ALIGNMENT INSTRUCTIONS—READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

Controls should be set as follow, except where otherwise noted: Bandsread dial to "Set". Control switch to "MVC". RF Gain at maximum, Tone switch to "High", & AF Gain at "Maximum". Attenuate output of sign. gen. to just obtain an output reading. Use an insulated alignment screwdriver for all adjustments.
To set dial turn tuning cap. fully closed and loosen the set screw in coupling on tuning cap. shaft. Turn dial until last line at low frequency end of dial is under the pointer and tighten set screw.

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	BAND SWITCH POS.	RADIO DIAL SETTING	OUTPUT METER	ADJUST	REMARKS
1 Direct	High side to center stator of tuning cap. Low side to chassis.	455KC	Band "E"	Tuning cap. fully open.	Across voice coil	A1,A2, A3,A4, A5,A6.	Adjust for maximum output.
2 "	"	455KC (Unmodulated)	"	"	"	A7	Control switch to "CWC". Loosen set screw on collar of "Pitch" control shaft, and remove knob and shaft from cabinet. Adjust A7 for zero beat thru hole in cabinet. Replace knob with white dot at midscale. Place collar with set screw directly opposite stop and tighten making certain that position of pitch control does not change from midscale.
3 300Ω carbon res.	High side to left ant. terminal. Low side to center ant. terminal with link disconnected.	54.0MC	Band "A"	54MC	"	A8	Adjust for maximum output. Tune sig. gen. to 53.1MC. If signal is not heard retune sig. gen. to 54MC and close A8 to next peak. Adjust for maximum output and recheck for image.
4 "	"	"	"	Tune for maximum output.	"	A9,A10	Rock tuning cap. and adjust for maximum output.
5 "	"	34.0MC	Band "B"	34MC	"	A11	Adjust for maximum output. Tune sig. gen. to 33.1MC. If signal is not heard, retune sig. gen. to 34MC and close A11 to next peak. Adjust for maximum output and recheck for image.
6 "	"	"	"	Tune for maximum output.	"	A12, A10	Rock tuning cap. and adjust for maximum output.
7 "	"	12.0MC	"	12MC	"	A13, A14, A15	Adjust for maximum output. Repeat Steps 5, 6 & 7 until no further improvement can be made.
8 "	"	"	Band "C"	"	"	A16	Adjust for maximum output. Tune sig. gen. to 12.9MC. If signal is not heard, retune sig. gen. to 12MC and open A16 to next peak. Adjust for maximum output and recheck for image.
9 "	"	"	"	Tune for maximum output.	"	A17, A10	Rock tuning cap. and adjust for maximum output.
10 "	"	4.4MC	"	4.4MC	"	A18, A19, A20	Adjust for maximum output. Repeat Steps 8, 9 and 10 until no further improvement can be made.
11 "	"	"	Band "D"	"	"	A21	Adjust for maximum output. Tune sig. gen. to 5.3MC. If signal is not heard, retune sig. gen. to 4.4MC and open A21 to next peak. Adjust for maximum output and recheck for image.
12 "	"	"	"	Tune for maximum output.	"	A22, A10	Rock tuning cap. and adjust for maximum output.
13 "	"	1.6MC	"	1.6MC	"	A23	Adjust for maximum output.
14 "	"	"	"	Tune for maximum output.	"	A24, A25	Bandsread dial to "zero". Adjust A24 & A25 for maximum output. Return bandsread dial to "Set". Repeat Steps 11, 12, 13 & 14 until no further improvement can be made.
15 "	"	.6MC	Band "E"	.6MC	"	A26, A27, A28	Bandsread dial to "Zero". Adjust A26, A27 & A28 for maximum output. Return bandsread dial to "Set".
16 "	"	1.5MC	"	1.5MC	"	A29	Adjust for maximum output.
17 "	"	"	"	Tune for maximum output.	"	A30, A10	Rock tuning cap. and adjust for maximum output. Repeat Steps 15, 16 & 17 until no further improvement can be made.

STAGE GAIN MEASUREMENTS

ANTENNA TO RF GRID	2X	600KC
RF GRID TO CONVERTER GRID	5X	600KC
CONVERSION GAIN	14X	IN 600KC OUT 455KC
1st IF TRANSFORMER	.4X	455KC
1st IF TUBE	30X	455KC
2nd IF TRANSFORMER	.5X	455KC
2nd IF TUBE	150X	455KC
3rd IF TRANSFORMER	.7X	455KC
AUDIO	25X	400 ~
OUTPUT	12X	400 ~

The stage gain measured values listed above are approximate values for an average operative stage, rather than an absolute value. It should be borne in mind that it is possible to introduce so many variables into the measurement operation, such as, type of equipment used for measuring, handling and placement of probes, the accuracy of alignment, etc., that an absolute reading is impractical. AVC is made inoperative by connecting negative (-) 3 volts to the AVC line.

K4XL's **BAMA**

This manual is provided **FREE OF CHARGE** from the "BoatAnchor Manual Archive" as a service to the Boatanchor community.

It was uploaded by someone who wanted to help you repair and maintain your equipment.

If you paid anyone other than BAMA for this manual, you paid someone who is making a profit from the free labor of others without asking their permission.

You may pass on copies of this manual to anyone who needs it. But do it without charge.

Thousands of files are available without charge from BAMA. Visit us at <http://bama.sbc.edu>